



Short U-Bolts
 For 2" wide x 3" deep, cross bolts X
 For 2" wide x 4" deep, straight bolts I I
Long U-Bolts
 For 3" wide x 3" deep, cross bolts X
 For 3" wide x 4" deep, straight bolts I I

INSTALLING HEAVY DUTY TIRE CARRIER

P/N 27310G

1. USE U-BOLTS CLOSEST TO THE SIZE OF YOUR TRAILER FRAME OR TONGUE.
2. Hold tire carrier to trailer tongue or frame and place u-bolts as shown around frame through top hole and bottom slot on each side of the tire bracket. Loosely secure u-bolts with washers and nuts.
3. When you have determined the tire carrier is located properly, tighten all four nuts evenly.
4. Place 1/2" carriage bolts from the back through square holes on the tire mounting plate. Top slot provides adjustment for 5-bolt rim with 4-1/2" bolt circle.
5. Use 3/4" box end wrench to place push nuts over carriage head bolts to hold them in place.
6. Put tire over bolts and secure with lug nut. Will accept 12", 13", 14" & 15" tires

PARTS INCLUDED (Use u-bolts closest to the size of your trailer)

1---U-bolt, 7/16" x 4-1/8" x 3-1/4"	15264	2---1/2" x 1-3/4" Carriage head bolt	11039
1---U-bolt, 7/16" x 4-1/8" x 3-1/4", formed	15265	2---1/2" Push nut	10802
1---U-bolt, 7/16" x 4-1/8" x 4-1/4"	15256	2---1/2" Lug nut	10845
1---U-bolt, 7/16" x 4-1/8" x 4-1/4", formed	15263		
4---7/16" Flat washer	10961		
4---7/16" Nylon locknut	10811		

